

Download Nortel M3904 Quick Reference Guide

Page 19: Transfer A Call (m3903 And M3904) Answer a call Transfer a call (M3903 and M3904) Use the Transfer feature to direct a call to a third party. To use the Transfer feature: 1. Press the Key. Transfer Trans The other party is on hold and you receive dial tone.Press the Speed Call Controller Key or Speed Call User Key. 3. Dial the Speed Call code assigned to the telephone number. Use Speed Call (M3903 and M3904) The Speed Call feature allows you to automatically dial frequently called numbers by entering a one, two, or three digit code.Nortel M3902 Quick Reference Manual. Download Quick reference manual of Nortel Meridian M3904 Adapter, IP Phone for Free or View it Online on All-Guides.com.Summary of Contents for Nortel M3902. Page 1 Meridian Digital Telephones M3902 M3903 M3904 Quick Reference Guide Enterprise Voice Solutions Customer Documentation... Page 3 Telephones There are five models in the M3900 Series Meridian Digital Telephone portfolio. This document describes the M3902, M3903, and M3904 features and how to use them.